



PowerBox PBX 90

Manual

Content

1 About PowerBox PBX 90	3
2 Hardware.....	4
2.1 Housing.....	4
2.2 Status LEDs	5
2.3 Connectors.....	6
2.4 Pin Configuration	7
2.5 Warnings and shutdown Thresholds.....	9
2.6 Mounting.....	9
3 PBX Suite Installation	10
4 The Structure Editor: Create a new configuration.....	11
4.1 Function Blocks	11
4.2 Utilities for placing and arranging of Function Blocks	13
4.3 Navigating through the configuration.....	14
4.4 Example "Blower Control"	14
4.5 Structuring of complex configurations.....	21
4.6 Utilities for navigating through complex configurations.....	23
4.7 Password protecting a configuration	23
5 First Upload of a configuration	24
6 Update of an existing configuration.....	26
7 The Powerbox Manager	27
7.1 Switch between configurations	27
7.2 View Live Data	29
7.3 Error log	30
8 Integration to RaceCon	32
9 FAQ	34
10 Legal	35
10.1 Legal Restrictions	35
10.2 REACH Statement.....	35
10.3 Open Source Software (OSS) declaration.....	35
11 Disposal	44
12 Technical Specifications	45

1 About PowerBox PBX 90

The Bosch PowerBox PBX 90 takes the whole Power Control Module concept much further than existing modules. It provides an effective and inspired alternative to conventional relays, circuit breakers, fuses and wires that can so often be a tangle of complexity and untidiness around a typical racing car's power junction box.

PowerBox PBX 90 is a compact and light weight module, measuring 214 x 159 x 57.5 mm (including connectors).

PowerBox PBX 90 has 36 outputs. All outputs are protected against reversed battery polarity. Current draw can be measured on all outputs from 500 mA .

Any of these channels can be controlled by various types and combinations of inputs. You'll find more information at Technical Specifications [► 45].

Instead of using a conventional control program, PowerBox PBX 90 benefits from a 667 MHz dual Core Processor and a multitasking operating system, allowing simultaneous executions of operations.

Please note that the maximum recommended current draw per channel is limited by the connector contacts (wiring loom side) - not by PowerBox PBX 90s driver stages. We have rated the individual channel's current draw in relation to the connector manufacturer's specifications.

PowerBox PBX 90 is programmed to shut overloaded channels down if the current draw or internal junction temperatures exceed pre-set levels.

A smart algorithm allows automatically turning-on of loads with a high inrush current.

The current draws and channel status can be logged internally and exported via one of the three available CAN busses.



WARNING

Please note that the PowerBox PBX 90 is not intended to be used to control safety-critical systems on a vehicle, such as ABS braking, power steering, etc..

Bosch Motorsport shall not be responsible for any incidental or consequential damages or injuries that may occur if the unit is used to control these, or similar, safety-critical systems.

2 Hardware

The Bosch PowerBox PBX 90 enclosure is partially CNC machined to the highest standards. The two parts of the casing are sealed by an O-ring, located in a recess in the main half. A lip in the lid presses on the O-ring and assures a protection against ingress of splash water. The connectors are individually sealed.

2.1 Housing



On the housing, you'll find the three connectors X1, X2 and X3 and the LEDs for **Failure**, **User**, **Power** and **Run**.

2.2 Status LEDs

Each LED on the PBX 90 has its own color code with different meanings.




The following table explains the different meanings:

Failure		Off No error
		Red solid At least one entry in the error log
		Red blinking (2 Hz) At least one active error present
User		Off/Blue Controlled by functionblock „User_LED“
		
Power		Off Power supply missing
		Green solid Power supply valid
Run		Green solid No configuration active
		Green blinking (2 Hz) Configuration active
		Orange blinking (2 Hz) Configuration error
		Orange solid Emergency state

2.3 Connectors


X1 PBX90

- 40 Ampere
- 25 Ampere
- 15 Ampere



X2 PBX90

- 40 Ampere
- 25 Ampere
- 15 Ampere



2.4 Pin Configuration

Connector X1: 38 way (ABS/ESR) Code 1			
Pin	Signal	Cont. [A]	Peak [A]
1	HP_OUT3	40	150
2	OUT22	15	100
3	PWM_OUT6	15	75
4	OUT21	15	100
5	ANA_IN07	0 to 5 V, Pull-up	
6	ANA_IN08	0 to 5 V, Pull-up	
7	PWM_OUT4	15	75
8	CAN_3_H	1 Mbaud max.	
9	SENSGND	GND for AIN[x]	
10	SENSPWR_5V	0.4	
11	PWM_OUT2	15	75
12	PWM_OUT1	15	75
13	HP_OUT4	40	150
14	ANA_IN03	0 to 5 V, Pull-up	
15	ANA_IN04	0 to 5 V, Pull-up	
16	DIG_IN3	0 to 12 V, Pull-up, Pull-down	
17	DIG_IN4	0 to 12 V, Pull-up, Pull-down	
18	ANA_IN09	0 to 5 V, Pull-up	
19	ANA_IN10	0 to 5 V, Pull-up	
20	CAN_3_L	1 Mbaud max.	
21	BAT_GND	15	100
22	BAT_GND	15	100
23	BAT_GND	15	100
24	BAT_GND	15	100
25	HP_OUT7	25	150
26	OUT19	15	100
27	ANA_IN05	0 to 5 V, Pull-up	
28	OUT20	15	100
29	ANA_IN06	0 to 5 V, Pull-up	
30	OUT17	15	100
31	OUT18	15	100
32	ANA_IN11	0 to 5 V, Pull-up	
33	OUT15	15	100
34	OUT16	15	100
35	ANA_IN12	0 to 5 V, Pull-up	
36	PWM_OUT3	15	75
37	PWM_OUT5	15	75
38	HP_OUT8	25	150

Connector X2: 38 way (ABS/ESR) Code 2			
Pin	Used for	Cont. [A]	Peak [A]
1	HP_OUT1	40	150
2	OUT14	15	100
3	OUT13	15	100
4	OUT02	15	100
5	OUT01	15	100
6	TIMESTAMP_INOUT	1 kHz open drain	
7	CAN_2_H	1 Mbaud max.	
8	CAN_1_H	1 Mbaud max.	
9	ETH_1_RXN	10/100 Mbps	
10	ETH_1_TXN	10/100 Mbps	
11	ETH_2_RXN	10/100 Mbps	
12	ETH_2_TXN	10/100 Mbps	
13	HP_OUT2	40	150
14	BAT_GND	15	100
15	ANA_IN01	0 to 5 V, Pull-up	
16	ANA_IN02	0 to 5 V, Pull-up	
17	DIG_IN1	0 to 12 V, Pull-up, Pull-down	
18	DIG_IN2	0 to 12 V, Pull-up, Pull-down	
19	CAN_2_L	1 Mbaud max.	
20	CAN_1_L	1 Mbaud max.	
21	ETH_1_RXP	10/100 Mbps	
22	ETH_1_TXP	10/100 Mbps	
23	ETH_2_RXP	10/100 Mbps	
24	ETH_2_TXP	10/100 Mbps	
25	HP_OUT5	25	150
26	OUT11	15	100
27	OUT09	15	100
28	OUT12	15	100
29	OUT10	15	100
30	OUT07	15	100
31	OUT08	15	100
32	LIN	Control of Bosch Motorsport LIN devices included. Support of other devices on request.	
33	OUT05	15	100
34	SHIELD_GND	shield	
35	OUT06	15	100
36	OUT03	15	100
37	OUT04	15	100
38	HP_OUT6	25	150

Connector X3: Amphenol Radsok Automotive Pinlock Connector 8 mm (35 mm², 50 mm²)

Pin	Used for	Cont. [A]	Peak [A]
1	BATT_POS	120	180

2.5 Warnings and shutdown Thresholds

Due to thermal or pin current overload, there are several warnings and shutdown thresholds. You can see an overview of these below.

Overcurrent

Warning overcurrent X3	140 A for 0.2 s
Shutdown overcurrent X3	180 A for 2 s

Overtemperature

Warning overtemperature CPU	95°C for 2 s
Shutdown overtemperature CPU	100°C for 2 s
Warning overtemperature Device	110°C for 2 s
Shutdown overtemperature Device	115°C for 2 s

2.6 Mounting

Hardware

Make sure that all connectors are plugged and locked before applying supply voltage. PowerBox PBX 90 will instantly start operation when supply is available.

Boot time is about 1 sec.

New hardware is preconfigured, no outputs will turn on.

3 PBX Suite Installation

The setup file for the PBX Suite is provided at the Bosch Motorsport internet homepage at the product page of the PowerBox PBX 90.

For the PBX Suite v2.5.0.3 and 2.5.1 or higher, no personal license key is required.

For older versions, a required personal license key can be requested by mail to LicenseMotorsport.BEG@de.bosch.com

The installation requires administrator rights.


Start the installation by running **setup.exe** and follow the wizard steps.

4 The Structure Editor: Create a new configuration

A configuration is the unit you exchange between the programming tool PBX Suite and your PowerBox PBX 90 after all changes and modifications.

For creating a configuration we developed the PBX Suite. This software tool enables visual programming of the configuration of your PowerBox.

- Start the program **PBX Suite**.
- Click **Structure Editor** in the menu box on the left side (1).




- Click **New** (2).
- Select your PBX type (3).
- Load the corresponding PST file (4).
- Confirm by clicking **OK** (5).

4.1 Function Blocks

The key technology of the PBX Suite is the function block. All functions of the PowerBox can be programmed and modified by using a string of function blocks.


Every function block is divided into three parts:



- **A** is the top part that includes the unique name of the function block. It is user changeable.

- **B** is the middle part that shows static parameters of the function block.
- **C** is the bottom part that shows dynamic input and output signals of the function block.

In part B and part C, the colored rectangles symbolize the signal connections: inputs on the left side and outputs on the right side.



1. Client assignment
2. Optional global block enable input.
3. Optional global block enable output, daisy-chained with input.
4. Signal input. Data type Boolean. Enabled for online view and export to RaceCon.
5. Signal output. Data type Integer. Enabled for online view and export to RaceCon.
6. Signal output. Data type Float. Enabled for online view and export to RaceCon.


As you will have realized in the steps 4 to 6, the system offers signals of three different data types:

- **Boolean** (Background color always GREEN)
- **Integer** (Background color always YELLOW)
- **Float** (Background color always ORANGE)

If function blocks are available as different data type, you can identify the data type from the background color of the inputs and outputs and from the end of the function blocks name. The last letter will show the data type.

Example:


The function block CAN_Input is available as data type Boolean or data type Integer or data type Float. To separate one from the other, we put a letter at the end of the function blocks name:



Color Scheme

The color of the function blockhead and the color of the symbol in the catalog both show the type of the function block:

- **blue** for functions
- **green** for inputs
- **red** for outputs



4.2 Utilities for placing and arranging of Function Blocks

At the **Layout** tab

- Rulers and Grid can be enabled or disabled,
- several functions helping to align the function blocks are available.



4.3 Navigating through the configuration

Use mouse wheel for zooming in or out.

Space bar toggles between current view and Zoom to Fit.

At the Quick Access Toolbar, several zoom options are provided.




Use **Overview** or **Zoom** tab for a second farer or closer view.



4.4 Example “Blower Control”


This chapter shows an example how to program the function **Blower Control** with the PBX Suite. The function shall start the cooling fan when the water temperature exceeds e.g. 90°C and stops it when the temperature falls below e.g. 80°C. You'll reach it by setting Default to 90 and Hysteresis to 10 as shown in the following instructions.

1. Start the PBX Suite.
2. Click **Structure Editor** in the menu box on the left side.




3. Click **New**.
4. Select your PBX Type.
5. Load the corresponding PST File.
6. Confirm by clicking **OK**.
7. Write **Input** in the text field of the Catalogue *[Insert here all words to filter, use “;” as separator]*.

8. Drag and Drop the function **Analog_Input** from the Catalogue onto the screen. The Analog_Input function block will pop up as shown in the following screenshot.




9. With double-click on the selected function block, you open the pin assignment wizard. Select Input X1_15 from the pull down menu. X1 is the connectors name and 15 is the pins name.




10. The assigned connector and pin are part of the function blocks name shown in the headline of the function block. Here it is X1_15, as you can see in the following screen shot.

Notice: All function blocks can be renamed by changing the name in Properties / Name.

With click on F1 while function block selected, you open the context sensitive online help. Here you find further information.




11. Write **Table** in the text field of the Catalogue.
12. Drag and Drop the function **OneDLookupTable** from the Catalogue onto the screen.




If you want to see the actual temperature in the Live Data later, please enable the OneDLookupTable by setting Y to enabled (red ring). Therefore you click on the or-

ange rectangle right of the Y. It gets red if activated. Choose Event Enabled -> True in the Properties block as shown in the following screenshot.




13. For more information about Live Data, please see View Live Data [▶ 29].

14. Double-click on the function OneDLookuptable opens a curve and a table where you can fill in your sensor data.




15. Write **hyst** in the text field of the Catalogue.


16. Drag and Drop the function **Hysteresis_left** from the Catalogue onto the screen. The Hysteresis_left function block will pop up as shown in the following screenshot.




17. For setting the default values click the orange square left to Lim in the Hysteresis_left function block. It changes color to red when activated. Sign in the value 90.0 as DefaultValue under Properties as shown in the following screenshot.




18. Set 10.0 as DefaultValue under Hyst in the same function block.




19. Write **output** in the text field of the Catalogue.
20. Drag and Drop the function **Highside HS_25A** from the Catalogue onto the screen.
The HS_25 function block will pop up as shown in the following screenshot.




21. With double-click on the selected function block you open the pin assignment wizard. Select Output X2_25 from the pull down menu, similar to step 9.



22. Connect the square angles of the function blocks by pulling lines as shown in the following screenshot.



23. Save the function by click on **Save** as shown in the following screenshot.



Congratulations! You have programmed your first function!

Further steps

After creating the configuration, you got the following options:


- transfer and activate the configuration to the PowerBox PBX 90 with PowerBox Manager,
- follow the signal values with PowerBox Manager,
- use the automatically generated *.prg file for RaceCon to measure, record and analyze, see also Integration to RaceCon [► 32].

Please visit our website bosch-motorsport.com for more information on how to work with the PBX suite.

4.5 Structuring of complex configurations

4.5.1 Layer

Use **Layer** mechanism for logically grouping of Function Blocks.




Function Blocks can belong to several Layers.

Layers are supported by the View Online Data of the Powerbox Manager allowing an easy filtering for the data of interest.


4.5.2 Container

1. Select two or more function blocks.
2. Right click on a selected function block to open the context menu
3. Select Create Container




A Container block appears which is connected to the environment.

In the properties tab a description, an image or an alternative name can be setup.




Double clicking the Container switches inside the container, showing the included function blocks and the outside connections.

Navigation to the outside is done in the lower left corner.




A further outside connection can be generated by

4. Right clicking on an in- or output port,
5. Select Add Connector to Container.



4.6 Utilities for navigating through complex configurations


At the **Ribbon** bar, several functions assist for finding, filtering, tracing, and selecting of Function Blocks in complex configurations.




4.7 Password protecting a configuration

Protecting a configuration with a password can be done by clicking the Button 'Save with password protection'.

Enter the password and confirm it.



From now on the correct password has to be entered to open this configuration.




5 First Upload of a configuration

This chapter will show how to upload the new designed configuration file to the PowerBox.


1. Connect your computer and the PowerBox via Ethernet.
2. Activate your PowerBox.
3. Start your PBX Suite and activate the PowerBox Manager by clicking on the button as shown in the following screenshot:




4. After a short while the screen will show your device:




5. Now you can transfer the config file. Therefore right-click on the device window and choose **Send Config and Start**:



6. Choose the configuration file which you want to put on your PowerBox. In this example it is named **Primeconfig.cfg**. Confirm with click on **Open**.




7. The config file was put on the PowerBox, and after an automatically restart the device window shows the name of the configuration:




6 Update of an existing configuration

This chapter will show how to update a configuration.

1. Click **Project Configuration** on Catalogue tab as shown in the following picture.




2. Select the corresponding PST file.



3. Confirm by clicking **OK**.

7 The Powerbox Manager

The Ribbon Bar




1. Refresh: Updates the current view
2. Emergency Flash: Allows to Flash a device which has entered the emergency state
3. Discover Devices: Used to assign in a double-PBX system the 2nd PBX device a different allocation

7.1 Switch between configurations


This chapter will show how to switch between different configurations on your PowerBox.

1. Right mouse click on the device window will open the menu as shown in the following screenshot.
2. Click **Stop** to end the active configuration.




3. Click **Start** to choose the new configuration.

4. Choose the new configuration from the pull-down menu, here "Secondconfig.cfg". Confirm with click on **Start**.




5. The device will restart, and after a short time the device window shows the name of the second configuration.




7.2 View Live Data

This chapter will show how you can view live data with your PowerBox Suite. Right click on your device opens a window where you choose View Live Data.



Now you can see the entire Event enabled data on your screen.



Every in- or output port of the Function Blocks checked for EventEnabled is represented as a row.

For output ports, the current value is shown, some with additional Description information.

For input ports, it is possible to affect the operative value. The result is controlled by the selected PoolingMode.

Various support for filtering the amount of data is provided, including the support for Layers.

7.3 Error log


A red dot in the upper right corner of the box indicates if the error log contains at least one entry.

If blinking, at least one active error entry is present.

Else only passive error(s) are present.

Machine Name:	PBX_A
Operating System:	PBX190_BASE_0103
Client ID:	A
Communication Group:	0
Configuration:	Secondconfig.cfg
Current Engine State:	Operation

In the context menu select **View Error Log** to view the error log entries.



Besides the location and type further information are available.

To clear the error log, click **Clear Error Log** in the upper left corner of the error log window.

Location	Type	First Occurrence	Duration (s)	Occurrences	Active	Info
HS_15A - X1_A	Overcurrent	01.01.2000 00:00:16	7.7	1	☐	No further information available

The Error Log can also be accessed with RaceCon.

RaceCon also provides access to the following measurements variables:


- General Error Log Status (device measurement label “error_state”)
 - No error present in memory
 - At least one inactive error present in memory, no active errors
 - At least one active error present in memory
- Error type (device label “error_type_rotate”)
 - e.g., “below_threshold” for a violation of the minimum voltage range defined in the configuration, “shortcut_Batt” for a shortcut to battery voltage etc.

- Error location (device label "error_location_rotate")
e.g., "ANA01" for an error concerning the first ANA channel
- Error active state (device label "error_active_rotate")
All failure modes are continuously diagnosed; any error detected will be written to the error memory. Once an error is detected, it is qualified as "active".
 - 1 (TRUE) Error was detected in most recent diagnose run (active)
 - 0 (FALSE) Error is inactive: error was not detected in most recent diagnostic run, however the error has not been cleared from the memory by the user and remains in the non-volatile memory


The aforementioned labels (error_active_rotate, error_location_rotate, error_type_rotate) cycle through the errors currently present in the memory and represent the respective property of each error periodically.

8 Integration to RaceCon

At the same location the Configuration is saved, an additional export file for RaceCon is written. It is suffixed by an „A‘ or „B‘ and the extension is ‚PRG‘:




Drag & Drop a PowerBox PBX 90 in RaceCon into the project and select this ‚PRG‘ file if asked for the program archive:



All the In- and Output Ports of the configuration with EventEnabled set to True are now available and can be used for

1. Logger
2. Display
3. Measuring



9 FAQ

You'll find an FAQ list on the PowerBox product site of [bosch-motorsport.com](https://www.bosch-motorsport.com).

10 Legal

10.1 Legal Restrictions

Due to embargo restrictions, sale of this product in Russia, Belarus, Iran, Syria, Libya, Afghanistan, and North Korea is prohibited.

10.2 REACH Statement

According to the REACH regulations, any supplier of an article containing a substance of very high concern (SVHC) in a concentration above 0.1 % (w/w) has the duty to provide the recipient of the article with sufficient information to allow safe use of the article. Our product contains:

SVHC Substance	CAS Number
Lead monoxide (lead oxide)	1317-36-8
Lead	7439-92-1

10.3 Open Source Software (OSS) declaration

10.3.1 antlr-2.7.7.jar License

ANTLR-2.7.7

SOFTWARE RIGHTS

ANTLR 1989-2006 Developed by Terence Parr

Partially supported by University of San Francisco & jGuru.com

We reserve no legal rights to the ANTLR--it is fully in the public domain. An individual or company may do whatever they wish with source code distributed with ANTLR or the code generated by ANTLR, including the incorporation of ANTLR, or its output, into commercial software.

We encourage users to develop software with ANTLR. However, we do ask that credit is given to us for developing ANTLR. By "credit", we mean that if you use ANTLR or incorporate any source code into one of your programs (commercial product, research project, or otherwise) that you acknowledge this fact somewhere in the documentation, research report, etc... If you like ANTLR and have developed a nice tool with the output, please mention that you developed it using ANTLR. In addition, we ask that the headers remain intact in our source code. As long as these guidelines are kept, we expect to continue enhancing this system and expect to make other tools available as they are completed.

The primary ANTLR guy:

Terence Parr

parrt@cs.usfca.edu

parrt@antlr.org

10.3.2 antlr311runtime.jar License

ANTLR-3.1.1

ANTLR 3 License

[The BSD License]

Copyright (c) 2010 Terence Parr

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of the author nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

10.3.3 crc32 License

Copyright (c) 2003 Markus Friedl. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

10.3.4 log4j.jar License

The Apache Software License, Version 1.1

Copyright (C) 1999 The Apache Software Foundation. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The end-user documentation included with the redistribution, if any, must include the following acknowledgment: "This product includes software developed by the Apache Software Foundation (<http://www.apache.org/>).". Alternately, this acknowledgment may appear in the software itself, if and wherever such third-party acknowledgments normally appear.
4. The names "log4j" and "Apache Software Foundation" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact apache@apache.org.
5. Products derived from this software may not be called "Apache", nor may "Apache" appear in their name, without prior written permission of the Apache Software Foundation.

THIS SOFTWARE IS PROVIDED "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE APACHE SOFTWARE FOUNDATION OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This software consists of voluntary contributions made by many individuals on behalf of the Apache Software Foundation. For more information on the Apache Software Foundation, please see <<http://www.apache.org/>>.

/

10.3.5 opencsv License

opencsv <http://opencsv.sourceforge.net> sconway@users.sourceforge.net arjones@t-online.de

Apache License

Version 2.0, January 2004

<http://www.apache.org/licenses/>

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works

that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition,

"submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

2. **Grant of Copyright License.** Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.
3. **Grant of Patent License.** Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.
4. **Redistribution.** You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
 - (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
 - (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
 - (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work excluding those notices that do not pertain to any part of the Derivative Works; and

(d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

5. **Submission of Contributions.** Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
6. **Trademarks.** This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.
7. **Disclaimer of Warranty.** Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
8. **Limitation of Liability.** In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.
9. **Accepting Warranty or Additional Liability.** While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if

You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

10.3.6 Sensor Driver for BMI160 Sensor

Copyright (c) 2021 Bosch Sensortec GmbH. All rights reserved.

BSD-3-Clause

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the copyright holder nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

10.3.7 stringtemplate License

[The "BSD licence"]

Copyright (c) 2003-2008 Terence Parr

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

10.3.8 xml_io_tools License

xml_io_tools

Copyright (c) 2007, Jaroslaw Tuszynski

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

10.3.9 Avalonia

The MIT License (MIT)

Copyright (c) .NET Foundation and Contributors All Rights Reserved

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

11 Disposal

Hardware, accessories and packaging should be sorted for recycling in an environment-friendly manner.

Do not dispose of this electronic device in your household waste.

12 Technical Specifications

Mechanical Data

Size	214 x 159 x 57.5 mm
Weight	830 g
Protection Classification	Protected against ingress of particles > 1 mm, splash water proof
Temp. range (at internal sensors)	-20 to 85°C
Max. vibration	Vibration profile 1 (see Downloads)

Electrical Data

Supply voltage range	5 to 20 V
Current consumption	<1 A
Maximum recommended output current	120 A continuously >180 A peak current (2 s)

Inputs

Number of digital inputs	4
Number of analogue inputs	12 x 0 to 5 V; 16 bit resolution
Number of CAN input channels	500

Outputs

All driver stages are thermally and reverse polarity protected.

Very high power channels

Number of individual outputs	4
Maximum continuously current draw per output	40 A
Maximum peak current each output	150 A inrush

High power channels

Number of individual outputs	4
Maximum continuously current draw per output	25 A
Maximum peak current each output	150 A inrush

Low power channels

Number of individual outputs	22
Maximum continuously current draw per output	15 A
Maximum peak current each output	100 A inrush

PWM channels

Number of individual outputs	6
Maximum continuously current draw per output	15 A

Maximum peak current each output	75 A inrush
Maximum applied frequency	20 kHz

Sensor supplies

Number of 5 V reference sensor supplies	1; 400 mA at 5 V
---	------------------

Communication

PC Interface	Ethernet
CAN bus	3
CAN protocol	2.0B
CAN baud rate (each CAN bus)	125/250/500/1000 Kbps
CAN identifiers	11 bit or 29 bit identifiers Motorola or Intel format Bit wise operator
LIN bus	1; Control of Bosch Motorsport LIN devices included. Support of other devices on request.
Ethernet	2 at 100 Mbit/s

Bosch Engineering GmbH

Motorsport

Robert-Bosch-Allee 1

74232 Abstatt

Germany

www.bosch-motorsport.com